



SCHOTT ColdVision Light Source Programming Guide

D20980.026 , Issue 1.0 – 04_OI_00177
March 2025

SCHOTT North America, Inc.
122 Charlton Street, Southbridge, MA 01550-1960
Phone: (508) 765-9744, Fax: (508) 765-1299
Email: lightingimaging@us.schott.com
Website: <https://www.schott.com/products/coldvision-fiber-optic-illumination>

Table of Contents

SCHOTT
glass made of ideas

Table of Contents

Introduction.....	3
Downloads.....	3
Comments	3
Remote Operation	4
Legacy Protocol.....	5
Command Structure	5
Negative Acknowledgements	5
Command Index.....	6
Command Details.....	9

Introduction

SCHOTT
glass made of ideas

Introduction

This Programming Guide is to explain the use of advanced interfaces of the Schott ColdVision Light Source. This document will be updated as new features are added to the software.

Downloads

All data sheets, manuals, firmware updates, and example software can be downloaded from the SCHOTT website at the following link:

<https://www.schott.com/products/coldvision-fiber-optic-illumination/downloads>

Comments

We welcome your feature requests and comments about this document.

You can reach us by e-mail at lightingimaging@us.schott.com

Remote Operation

The CV-LS has several remote operation interfaces. Any interface using the legacy protocol can be connected to using most terminal applications. Possible interfaces and their default connection information can be found below:

- ❖ Legacy Protocol
 - Ethernet Socket
 - Set terminal application to Telnet
 - Port 50811
 - Static IP Address 192.168.0.2
 - DHCP Enabled
 - UART
 - 9600 Baud
 - 8 Bit
 - 1 Stop Bit
 - No Parity
 - RX, TX, and GND must be connected through the Multiport
 - USB
 - CV-LS USB Driver must be installed
 - Terminal application will show the CV-LS as a RS232 port, but no additional settings are needed
- ❖ Binary Protocol
 - Ethernet Socket
 - Port 5000
 - Static IP Address 192.168.0.2
 - DHCP Enabled

Legacy Protocol

Command Structure

All commands start with the ampersand character “&” and end with a carriage return “\r”. There is a string representing the command immediately after the “&”, followed by the desired value.

The unit will discard all characters until it receives an “&” start character. Once the carriage return “\r” is received, the unit will process the command. If a valid command is not found, the unit will return “&n” followed by the command string with an indicator of which character was not recognized.

Negative Acknowledgements

Negative acknowledgements are used to indicate that a received command was invalid. The following negative acknowledgements are supported.

INVALID COMMAND:	Return string format: &nXpY &n = Negative acknowledgement X = Received characters parsed correctly p = Invalid character location start Y = Invalid character received
INVALID PARAMETER:	Return string format: &nXpYYY &n = Negative acknowledgement X = Received characters parsed correctly p = Invalid parameter location start Y = Invalid parameter received

Command Index

1 System Status	9
1.1 Temperature.....	9
1.1.1 Board.....	9
1.1.2 LED	9
1.2 Voltage Monitors	10
1.2.1 Input.....	10
1.2.2 Reference 5V Output	10
1.3 Fan	10
1.3.1 Speed.....	10
1.3.2 Status	11
1.4 Equalizer.....	11
1.4.1 Stability	11
1.4.2 Status	11
1.5 System Information.....	11
1.5.1 System Mode	11
1.5.2 User Mode.....	11
1.5.3 Time	12
1.6 Light Feed Back Raw.....	12
1.7 Error Flags.....	12
1.8 Inputs	12
1.8.1 Analog	12
1.8.2 Digital	12
1.9 Identification	13
1.9.1 Product Name	13
1.9.2 Firmware Revision.....	13
1.9.3 Serial Number	13
1.9.4 Model.....	13
1.9.5 Model:Serial	13
1.10 Memory Write Cycles	14
1.10.1 Factory Settings.....	14
1.10.2 User Settings	14
1.10.3 SPI (Firmware Uploads).....	14
1.10.4 Error Logs	14
2 Configurations	15
2.1 Persistent Memory.....	15

2.1.1	Save Settings	15
2.1.2	Restore Settings	15
2.2	Factory Defaults	15
2.2.1	Restore All Factory Defaults.....	15
2.2.2	Restore Factory Defaults (Preserving Network Settings).....	15
2.2.3	Erase Exception Logs.....	15
2.2.4	Reboot System	15
3	Controls	16
3.1	Control Mode.....	16
3.1.1	Last Command Interface	16
3.2	LED Channel Settings.....	16
3.2.1	Demo Mode (RGBW Model Only).....	16
3.2.2	Combined Trigger.....	16
3.2.3	Knob Mode.....	16
3.2.4	Single Channel Operation	16
3.2.5	Shut-Down Pin	17
3.2.6	Output Enable (Front Switch)	17
3.2.7	Output Power (Front Knob)	18
3.3	Continuous Strobe.....	19
3.3.1	Continuous Strobe Enable.....	19
3.3.2	Single Channel Operation	19
3.3.3	Frequency.....	19
3.3.4	Duty Cycle	19
3.3.5	Phase Shift.....	20
3.3.6	Waveform Polarity	20
3.4	Triggered Strobe	21
3.4.1	Triggered Strobe Enable.....	21
3.4.2	Combined Trigger.....	21
3.4.3	Single Channel Operation	21
3.4.4	Delay	21
3.4.5	On Time.....	22
3.4.6	Trigger Edge	22
3.5	Equalizer.....	23
3.5.1	Equalizer Enable	23
3.5.2	Start-up Delay	23
3.5.3	Target Light Output.....	23
3.5.4	Current Light Output.....	23

3.5.5	Equalizer Output	23
3.6	Fan Settings	24
3.6.1	Manual Fan Control	24
3.6.2	Fan Speed.....	24
4	Settings.....	25
4.1	General.....	25
4.1.1	Login Timeout	25
4.1.2	Require Login	25
4.1.3	Allow Browser Save Password	25
4.1.4	Controls Lockout	26
4.2	Network.....	27
4.2.1	Connection Status	27
4.2.2	Hostname.....	27
4.2.3	DHCP	27
4.2.4	IP Address.....	27
4.2.5	Subnet Mask.....	28
4.2.6	Gateway	28
4.2.7	Preferred DNS	29
4.2.8	Alternate DNS.....	29
4.3	Sockets	30
4.3.1	Legacy Ethernet Socket.....	30
4.3.2	Binary Ethernet Socket.....	31
4.4	UART	32
4.4.1	Baud Rate	32
4.4.2	Parity	32
4.4.3	Stop Bits	32
4.4.4	Restart.....	32
5	Other Commands.....	33
5.1	Erase Error Logs.....	33
5.2	System Reboot.....	33

Command Details

1 System Status

1.1 Temperature

1.1.1 Board

&?BM	Get current thermistor status of the main PCB Return string: &?bmX Return value (X): 1 = Good, 2 = Warning, 3 = Error
&?BS	Get status of the temperature sensor on the main PCB Return string: &?bsX Return value (X): 1 = Fully Functional, 0 = Warning or Error
&?BT	Get current temperature of the main PCB in Celsius Return string: &?btX Return value (X): 0.0 – 100.0

1.1.2 LED

1.1.2.1 Legacy

&CT?	Get current temperature of the LED PCB in Celsius (Legacy Command, See &?lt). Return string: &ctX Return value (X): LED Temp in "XX" format. Note: Unit will accept command without (?) for backwards compatibility.
------	--

1.1.2.2 CV-LS

&?LM	Get current thermistor status of the LED PCB Return string: &?lmX Return value (X): 1 = Good, 2 = Warning, 3 = Error
&?LS	Get status of the temperature sensor on the LED PCB Return string: &?lsX Return value (X): 1 = Fully Functional, 0 = Warning or Error
&?LT	Get current temperature of the LED PCB in Celsius Return string: &?ltX Return value (X): 0.0 – 100.0

Legacy Protocol

SCHOTT
glass made of ideas

System Status

1.2 Voltage Monitors

1.2.1 Input

1.2.1.1 Voltage

&?VI	Get the voltage of the input rail. This will be the higher voltage of the 2 inputs to the unit. Input Voltage is rated for 18 - 28V. Return string: &?viX.XX Return value (X.XX): Floating Point Voltage with 2 decimal places
-----------------	---

1.2.1.2 Status

&?VIS	Gets the status of the input rail. This will report a warning as the voltage nears its range, then turn to an error before the unit shuts down. Warning = V > 28 or V < 19 Error = V > 30 or V < 18 System shutdown will occur near 17.5V and will not turn on again below 18V. Voltage above 33V will damage the LED driver circuit. Return string: &?visX Return value (X): 1 = Good, 2 = Warning, 3 = Error
------------------	---

1.2.2 Reference 5V Output

1.2.2.1 Voltage

&?VO	Get the actual voltage of the 5V reference pin on the multiport. Output Reference Voltage is 5V +/- 0.1V. Return string: &?voX.XX Return value (X.XX): Floating Point Voltage with 2 decimal places
-----------------	--

1.2.2.2 Status

&?VOS	Gets the status of the 5V reference rail. This will report a warning as the voltage is pulled out of regulation. This would generally be caused by overloading the output regulator. Warning = >10% Error = >25% Return string: &?vosX Return value (X): 1 = Good, 2 = Warning, 3 = Error
------------------	---

1.3 Fan

1.3.1 Speed

&?G	Gets the current fan speed in RPM Return string: &?gX Return value (X): 0 – 24000
----------------	---

Legacy Protocol

System Status

SCHOTT
glass made of ideas

1.3.2 Status

&?GS	Gets the current fan status Return string: &?gsX Return value (X): 0 = Off 1 = Good 2 = Warning 3 = Error 4 = Info
-----------------	--

1.4 Equalizer

1.4.1 Stability

&ES?	Gets the Equalizer Stability Return string: &esX Return value (X): 0 = non stable 1 = Locked (stable) 2 = Waiting for delay to start 4 = intensity low 6 = intensity high 8 = over range (intensity too low to maintain stability) 10 = under range (intensity too high to maintain stability)
-----------------	--

1.4.2 Status

&ESD?	Gets the Equalizer Status Return string: &esdX Return value (X): 0 = Off 1 = Good 2 = Warning 3 = Error 4 = Info
------------------	--

1.5 System Information

1.5.1 System Mode

&?SM	Gets the current operating mode of the system Return string: &?smX Return value (X):
-----------------	---

1.5.2 User Mode

&?SU	Gets the current user mode. This can be overridden with individual commands. Return string: &?suX Return value (X):
-----------------	--

Legacy Protocol

System Status

SCHOTT
glass made of ideas

1.5.3 Time

&?ST	Gets the current system time in seconds from the epoch. Return string: &?stX Return value (X):
-----------------	---

1.6 Light Feed Back Raw

&?I	Gets the current raw value of the Light Feed Back sensor. Return string: &?iX Return value (X): 0 – 4096
----------------	---

1.7 Error Flags

&C?	Reports any error flags for the system. Return string: &cX Return value (X): 8 bit value, Bit 0 = Fan Error, Bit 1 = LED Temp Error, Bit 8 = Any Faults. Bit values: 1 = Fault Exists, 0 = No Fault Exists. Note: Unit will accept command without (?) for backwards compatibility.
----------------	---

1.8 Inputs

1.8.1 Analog

&?A#	Gets current value of an analog channel specified by #. Input Options (#): 0 = Front Knob, 1-4 = Multiport Analog Channel Input Return string: &?a#X Return value (X): 0 – 1000
-----------------	---

1.8.2 Digital

&?D#	Gets current value of a digital channel specified by #. Input Options (#): 0 = Front Switch, 1-4 = Multiport Digital Channel Input Return string: &?d#X Return value (X): 0 – 1000
-----------------	--

Legacy Protocol

System Status

SCHOTT
glass made of ideas

1.9 Identification

1.9.1 Product Name

&Q	Gets a string containing the product name. Return value: &q SCHOTT ColdVision Light Source
---------------	--

1.9.2 Firmware Revision

&F?	Gets the firmware revision of the unit. Return String: &fX.XX Return value (X.XX): Firmware Revision Note: Unit will accept command without (?) for backwards compatibility.
----------------	--

1.9.3 Serial Number

&Z?	Gets unit Serial Number. Return string: &zXXXXXX Return value (XXXXXX): 6 digit serial number Note: Unit will accept command without (?) for backwards compatibility.
----------------	---

1.9.4 Model

&ZM?	Gets unit Model Return string: &zmY Return value (Y): Model String Note: Unit will accept command without (?) for backwards compatibility.
-----------------	--

1.9.5 Model:Serial

&ZF?	Gets unit Model:Serial number. Return string: &zfy:XXXXXX Return value (Y): Model String Return value (XXXXXX): 6 digit serial number Note: Unit will accept command without (?) for backwards compatibility.
-----------------	--

1.10 Memory Write Cycles

1.10.1 Factory Settings

&?MF	Get the number of times the Factory Settings have been stored to memory. Rated for 1,600,000 write cycles. Return string: &?mfX Return value (X): Write Count
-----------------	---

1.10.2 User Settings

&?MS	Get the number of times the User Settings have been stored to memory. Rated for 40,000,000 write cycles. Return string: &?msX Return value (X): Write Count
-----------------	---

1.10.3 SPI (Firmware Uploads)

&?MP	Get the number of times the user has written to the firmware flash memory. Rated for 10,000 write cycles. Return string: &?mpX Return value (X): Write Count
-----------------	--

1.10.4 Error Logs

&?ML	Get the number of times an Error Log has been stored to memory. Rated for 25,600,000 write cycles. Return string: &?mlX Return value (X): Write Count
-----------------	---

Legacy Protocol

Configurations

SCHOTT
glass made of ideas

2 Configurations

2.1 Persistent Memory

2.1.1 Save Settings

&S	Command forces the unit to store the current settings to non-volatile memory. Return string: &s
---------------	---

2.1.2 Restore Settings

&T	Command forces the unit to restore the current settings to those stored in non-volatile. Return string: &t
---------------	--

2.2 Factory Defaults

2.2.1 Restore All Factory Defaults

&0	This command causes the unit to return to all settings stored at the factory. Return string: &o
---------------	---

2.2.2 Restore Factory Defaults (Preserving Network Settings)

&02	This command causes the unit to return to all settings stored at the factory, but will keep the current network settings. Return string: &o2
----------------	--

2.2.3 Erase Exception Logs

&03	This command causes the unit to erase any current exceptions from the log. Return string: &o3
----------------	---

2.2.4 Reboot System

&04	This command causes the unit to reboot the processor. This has the same effect as power cycling the unit. Return string: &o4
----------------	--

Controls

3 Controls

3.1 Control Mode

3.1.1 Last Command Interface

&M#	Gets which interface was the last to accept a command change to the system. Input Options (#): 0 = Front, 1 = Multiport, 2 = RS232, 3 = Legacy Socket, 4 = USB, 5 = Web Interface, 6 = Binary Socket, ? = Query Return string: &mX Return value (X): 0 = Front, 1 = Multiport, 2 = RS232, 3 = Legacy Socket, 4 = USB, 5 = Web Interface, 6 = Binary Socket
----------------	--

3.2 LED Channel Settings

3.2.1 Demo Mode (RGBW Model Only)

&D#	Gets/Sets if the unit is operating in demo mode. This command is for RGBW units to demonstrate color mixing possibilities. Input Options (#): 0 = Disable, 1 = Enable, ? = Query Return string: &dX Return value (X): 0 = Disable, 1 = Enable
----------------	---

3.2.2 Combined Trigger

&j0,#	Control to combine all inputs together. When enabled, input to any channel behaves as if all inputs were wired together. Input Option (#): 0 = Disabled, 1 = Enabled, ? = Query Return string: &j0,X Return value (X): 0 = Disabled, 1 = Enabled
------------------	--

3.2.3 Knob Mode

&n#	Gets/Sets the function of the front knob. Input Options (#): 0 = Common, 1 – 4 = Channel, 5 = Demo Mode, ? = Query Return string: &nX Return value (X): 0 = Common, 1 – 4 = Channel, 5 = Demo Mode
----------------	---

3.2.4 Single Channel Operation

&b#	Gets/Sets if the driver is single or quad channel. Input Options (#): 0 = Quad, 1 = Single, ? = Query Return string: &bX Return value (X): 0 = Quad, 1 = Single
----------------	---

Legacy Protocol

Controls

SCHOTT
glass made of ideas

3.2.5 Shut-Down Pin

&J#,#	Gets/Sets the behavior of the digital inputs on the Multiport connector. Default is Active Low, where a low signal (GND) will turn off that channel of the LED. First Input Option (#): 1 – 4 = Channel Second Input Option (#): 0 = Active Low, 1 = Active High, ? = Query Return string: &jX,Y Return value (X): 1 – 4 = Channel Return value (Y): 0 = Active Low, 1 = Active High
------------------	--

3.2.6 Output Enable (Front Switch)

3.2.6.1 Legacy

&L#	Gets/Sets if the LED control loop is active. This is equivalent to pressing the button on the front of the unit. Input Options (#): 0 = Disabled, 1 = Enabled, ? = Query Return string: &1X Return value (X): 0 = Disabled, 1 = Enabled
----------------	---

3.2.6.2 CV-LS

&L#,#	Gets/Sets if the LED control loop is active. First Input Option (#): 0 = Common, 1 – 4 = Channel Second Input Option (#): 0 = Disabled, 1 = Enabled, ? = Query Return string: &1X,Y Return value (X): 0 = Common, 1 – 4 = Channel Return value (Y): 0 = Disabled, 1 = Enabled
------------------	---

Legacy Protocol

Controls

SCHOTT
glass made of ideas

3.2.7 Output Power (Front Knob)

3.2.7.1 Legacy

&I#	Gets/Sets the common power limit for the LED. This has the same effect as turning the front knob. Input Options (#): 0 – FF = LED Power in HEX, ? = Query Return string: &iX Return value (X): 00 – FF = LED Power in 2 digit HEX
&IP#	Gets/Sets the common power limit for the LED with High Resolution. This has the same effect as turning the front knob. Input Options (#): 0 – 7FF = LED Power in HEX, ? = Query Return string: &ipX Return value (X): 000 – 7FF = LED Power in 3 digit HEX

3.2.7.2 CV-LS

&I#,#	Gets/Sets the power limit for the LED. First Input Option (#): 0 = Common, 1 – 4 = Channel Second Input Option (#): 0 – 1000 = Channel Power, ? = Query Return string: &iX,Y Return value (X): 0 = Common, 1 – 4 = Channel Return value (Y): 0 – 1000 = Channel Power
------------------	---

3.3 Continuous Strobe

3.3.1 Continuous Strobe Enable

&RM#	Gets/Sets if the continuous strobe mode is enabled. Input Options (#): 0 = Disabled, 1 = Enabled, ? = Query Return string: &rmX Return value (X): 0 = Disabled, 1 = Enabled
-----------------	---

3.3.2 Single Channel Operation

&RB#	Gets/Sets if the unit will behave as a single channel device during continuous strobe. Input Options (#): 0 = Quad Channel Mode, 1 = Single Channel Mode, ? = Query Return string: &rbX Return value (X): 0 = Quad Channel Mode, 1 = Single Channel Mode
-----------------	---

3.3.3 Frequency

&RF#	Gets/Sets the frequency that the continuous strobe operates at. Input Options (#): 6 – 20000 = Frequency in Hz, ? = Query Return string: &rfX Return value (X): 6 – 20000 = Frequency in Hz
-----------------	---

3.3.4 Duty Cycle

3.3.4.1 Legacy

&RD#	Gets/Sets the time that the LED is active during the strobe event. Input Options (#): 0 – 1000 = Duty Cycle, ? = Query Return string: &rdX Return value (X): 0 – 1000 = Duty Cycle
-----------------	--

3.3.4.2 CV-LS

&RD#, #	Gets/Sets the time that the LED channel is active during the strobe event. First Input Option (#): 1 – 4 = Channel Second Input Option (#): 0 – 1000 = Duty Cycle, ? = Query Return string: &rdX, Y Return value (X): 1 – 4 = Channel Return value (Y): 0 – 1000 = Duty Cycle
--------------------	---

Legacy Protocol

SCHOTT
glass made of ideas

Controls

3.3.5 Phase Shift

3.3.5.1 *Legacy*

&RP#	Gets/Sets the amount of offset from the internal trigger. Input Options (#): 0 – 1000 = Phase Shift, ? = Query Return string: &rpX Return value (X): 0 – 1000 = Phase Shift
-----------------	---

3.3.5.2 *CV-LS*

&RP#,#	Gets/Sets the amount of offset per channel from the internal trigger. First Input Option (#): 1 – 4 = Channel Second Input Option (#): 0 – 1000 = Phase Shift, ? = Query Return string: &rpX,Y Return value (X): 1 – 4 = Channel Return value (Y): 0 – 1000 = Phase Shift
-------------------	---

3.3.6 Waveform Polarity

&RJ#,#	Gets/Sets whether the active part of the waveform has the LED On or Off. The LED will be on with an Active High setting, or Off with an Active Low setting, during the set Duty Cycle %. First Input Option (#): 1 – 4 = Channel Second Input Option (#): 0 = Active Low, 1 = Active High, ? = Query Return string: &rjX,Y Return value (X): 1 – 4 = Channel Return value (Y): 0 = Active Low, 1 = Active High
-------------------	--

3.4 Triggered Strobe

3.4.1 Triggered Strobe Enable

&PM#	Gets/Sets if the triggered strobe mode is enabled. Input Options (#): 0 = Disabled, 1 = Enabled, ? = Query Return string: &pmX Return value (X): 0 = Disabled, 1 = Enabled
-----------------	--

3.4.2 Combined Trigger

&PJ0,#	Gets/Sets if the system will use an input on any digital input to trigger all channels simultaneously. Input Options (#): 0 = Disable, 1 = Enable, ? = Query Return string: &pj0,X Return value (X): 0 = Disable, 1 = Enable
-------------------	--

3.4.3 Single Channel Operation

&PB#	Gets/Sets if the unit will behave as a single channel device during triggered strobe. Input Options (#): 0 = Quad Channel Mode, 1 = Single Channel Mode, ? = Query Return string: &pbX Return value (X): 0 = Quad Channel Mode, 1 = Single Channel Mode
-----------------	--

3.4.4 Delay

3.4.4.1 Legacy

&PD#	Gets/Sets the time delay between arrival of a trigger input and the LED emitting light. There is a system delay of 4-9 microseconds, followed by the variable delay. Input Options (#): 0 – 1000000 = Delay in Microseconds, ? = Query Return string: &pdx Return value (X): 0 – 1000000 = Delay in Microseconds Note: For backwards compatibility return value will be padded with leading zeros to have at least 4 digits.
-----------------	---

3.4.4.2 CV-LS

&PD#, #	Gets/Sets the time delay between arrival of a trigger input and the LED emitting light. There is a system delay of 4-9 microseconds, followed by the variable delay. First Input Option (#): 1 – 4 = Channel Second Input Option (#): 0 – 1000000 = Delay in Microseconds, ? = Query Return string: &pdx,Y Return value (X): 1 – 4 = Channel Return value (Y): 0 – 1000000 = Delay in Microseconds
--------------------	--

3.4.5 On Time

3.4.5.1 *Legacy*

&P0#	Gets/Sets the time that the LED channel is active during the strobe. Input Options (#): 0 – 1000000 = On Time in Microseconds, ? = Query Return string: &poX Return value (X): 0 – 1000000 = On Time in Microseconds Note: For backwards compatibility, any value will be accepted, but the internal timer has a 5 microsecond resolution.
-----------------	--

3.4.5.2 *CV-LS*

&P0#,#	Gets/Sets the time that the LED channel is active during the strobe. First Input Option (#): 1 – 4 = Channel Second Input Option (#): 0 – 1000000 = On Time in Microseconds, ? = Query Return string: &poX,Y Return value (X): 1 – 4 = Channel Return value (Y): 0 – 1000000 = On Time in Microseconds Note: For backwards compatibility, any value will be accepted, but the internal timer has a 5 microsecond resolution.
-------------------	---

3.4.6 Trigger Edge

&PJ#,#	Gets/Sets if the system triggers on the Rising or Falling edge of an input signal. First Input Option (#): 1 – 4 = Channel Second Input Option (#): 0 = Rising Edge, 1 = Falling Edge, ? = Query Return string: &pjX,Y Return value (X): 1 – 4 = Channel Return value (Y): 0 = Rising Edge, 1 = Falling Edge
-------------------	--

Legacy Protocol

Controls

SCHOTT
glass made of ideas

3.5 Equalizer

3.5.1 Equalizer Enable

&E#	Gets/Sets if the system equalizer is enabled. Input Options (#): 0 = Disable, 1 = Enable, ? = Query Return string: &eX Return value (X): 0 = Disable, 1 = Enable
----------------	--

3.5.2 Start-up Delay

&EI#	Gets/Sets the time delay from turning on the unit to passing control of the light output to the equalizer control loop. Input Options (#): 0 – 500 = Delay in Decimal Format, ? = Query Return string: &eiX Return value (X): 0 – 500 in 3 digit Decimal Format “&eeXXX”
-----------------	--

3.5.3 Target Light Output

&EE#	Gets/Sets the target value used in the equalizer control loop. Input Options (#): 0 – 4095 = Target Value in Hex Format, ? = Query Return string: &eeX Return value (X): 0 – 4095 in 3 digit Hex Format “&eeXXX”
-----------------	--

3.5.4 Current Light Output

&EV?	Returns the current Light Feed Back value used in the equalizer control loop. This value is averaged over time from the raw Light Feed Back (LFB) value of the system. Return string: &evX Return value (X): 0 – 4095 in 3 digit Hex Format “&eeXXX” Note: Unit will accept command without (?) for backwards compatibility.
-----------------	---

3.5.5 Equalizer Output

&ED?	Gets the current output power from the equalizer control loop in Hex format. Return string: &edX Return value (X): 0 – 4095 in 3 digit Hex Format “&edXXX” Note: Unit will accept command without (?) for backwards compatibility.
-----------------	---

Legacy Protocol

Controls

SCHOTT
glass made of ideas

3.6 *Fan Settings*

3.6.1 Manual Fan Control

&GE#	Gets/Sets the fan override control. When the fan override is active, the fan will turn on to the set speed regardless of the state of the unit. The fan will remain on for 15 seconds after the last fan setting change. Input Options (#): 0 = Auto Mode, 1 = Manual Mode, ? = Query Return string: &geX Return value (X): 0 = Auto Mode, 1 = Manual Mode
-----------------	--

3.6.2 Fan Speed

&GS#	Gets/Sets the fan speed set point control. Input Options (#): 0 = Auto Input Options (#): 0 – 1000 = Target Speed, ? = Query Return string: &gsX Return value (X): 0 – 1000 = Target Speed
-----------------	--

4 Settings

4.1 General

4.1.1 Login Timeout

&HTE#	Gets/Sets the timeout enable for login sessions on all interfaces. Input Options (#): 0 = Disable, 1 = Enable, ? = Query Return string: &hteX Return value (X): 0 = Disable, 1 = Enable
&HT#	Gets/Sets the timeout settings for login sessions on all interfaces. Input Options (#): 1 – 30 = Timeout in Minutes, ? = Query Return string: &htX Return value (X): 1 – 30 = Timeout in Minutes

4.1.2 Require Login

&HRA#	Gets/Sets the requirement to login for ADMIN level pages. Input Options (#): 0 = Disable, 1 = Enable, ? = Query Return string: &hraX Return value (X): 0 = Disable, 1 = Enable
&HRC#	Gets/Sets the requirement to login for USER level pages. Input Options (#): 0 = Disable, 1 = Enable, ? = Query Return string: &hrcX Return value (X): 0 = Disable, 1 = Enable

4.1.3 Allow Browser Save Password

&HS#	Gets/Sets whether a web browser will offer to remember passwords to the user when logging in. Input Options (#): 0 = Disable, 1 = Enable, ? = Query Return string: &hsX Return value (X): 0 = Disable, 1 = Enable
-----------------	---

Legacy Protocol

Other Commands

SCHOTT
glass made of ideas

4.1.4 Controls Lockout

4.1.4.1 *Legacy*

&K#	Gets/Sets which external inputs are enabled on the unit. Input Options (#): 0 = No Lockouts, 1 = Front Lockout Only, 2 = Multiport Lockout Only, 3 = Both Front and Multiport Lockout, ? = Query Return string: &kX Return value (X): 0 = No Lockouts, 1 = Front Lockout Only, 2 = Multiport Lockout Only, 3 = Both Front and Multiport Lockout
----------------	---

4.1.4.2 *CV-LS*

&HLF#	Gets/Sets the lockout status of the front switch and front knob on the unit. Input Options (#): 0 = Disable, 1 = Enable, ? = Query Return string: &hlfx Return value (X): 0 = Disable, 1 = Enable Note: Front Button will still respond to factory reset override, even when the front controls are locked out.
&HLM#	Gets/Sets the lockout status of the analog controls on the Multiport. Input Options (#): 0 = Disable, 1 = Enable, ? = Query Return string: &hlmX Return value (X): 0 = Disable, 1 = Enable Note: Digital inputs will still respond allowing for remote switch controls of the unit.

4.2 Network

4.2.1 Connection Status

&AU?	Gets the network interface's connection status. Return string: &auX Return value (X): 1 = Net Connection Present, 0 = No Net Connection Note: Current driver does not support this function, so command will always return &au1 .
-----------------	---

4.2.2 Hostname

&AH#	Gets/Sets the network host name of the unit. This string appears in the network finder application, and can be used to distinguish units on the network. Input Options (#): Host Name String (no space), ? = Query Return string: &ahX Return value (X): Host Name String
-----------------	---

4.2.3 DHCP

&AM#	Gets/Sets if DHCP is enabled. Input Options (#): 0 = Disabled, 1 = Enabled, 2 = Restart Stack, ? = Query Return string: &amX Return value (X): 0 = Disabled, 1 = Enabled, 2 = Restarting Stack
-----------------	--

4.2.4 IP Address

&AID?	Gets the network interface's Dynamically assigned IP. Return string: &aidX Return value (X): IP in format "xxx:xxx:xxx:xxx" Note: If DHCP is disabled command will return "000:000:000:000" for the IP address. Note: Unit will accept command without (?) for backwards compatibility.
&AIS#	Gets/Sets the network interface's static IP. Input Options (#): IP address, ? = Query Return string: &aisX Return value (X): IP in format "xxx:xxx:xxx:xxx" Note: Unit will accept IP addresses separated with ":" and leading 0's for backwards compatibility, but will also accept standard format IP addresses.

4.2.5 Subnet Mask

&ASD?	Gets the network interface's Dynamically assigned Subnet Mask. Return string: &asdX Return value (X): Mask in format "xxx:xxx:xxx:xxx" Note: If DHCP is disabled command will return "000:000:000:000" for the IP address. Note: Unit will accept command without (?) for backwards compatibility.
&ASS#	Gets/Sets the network interface's static Subnet Mask. Input Options (#): Mask address, ? = Query Return string: &assX Return value (X): Mask in format "xxx:xxx:xxx:xxx" Note: Unit will accept Subnet Mask separated with ":" and leading 0's for backwards compatibility, but will also accept standard format Subnet Mask.

4.2.6 Gateway

&AGD?	Gets the network interface's Dynamically assigned gateway IP. Return string: &agdX Return value (X): IP in format "xxx:xxx:xxx:xxx" Note: If DHCP is disabled command will return "000:000:000:000" for the IP address. Note: Unit will accept command without (?) for backwards compatibility.
&AGS#	Get/Set the network interface's static gateway IP. Input Options (#): IP address, ? = Query Return string: &agsX Return value (X): IP in format "xxx:xxx:xxx:xxx" Note: Unit will accept IP addresses separated with ":" and leading 0's for backwards compatibility, but will also accept standard format IP addresses.

4.2.7 Preferred DNS

&ADD?	Gets the network interface's Dynamically assigned primary DNS IP. Return string: &addX Return value (X): Primary DNS IP in format "xxx:xxx:xxx:xxx" Note: If DHCP is disabled command will return "000:000:000:000" for the IP address. Note: Unit will accept command without (?) for backwards compatibility.
&ADS#	Get/Set the network interface's static primary DNS IP. Input Options (#): IP address, ? = Query Return string: &adsX Return value (X): Primary DNS IP in format "xxx:xxx:xxx:xxx" Note: Unit will accept IP addresses separated with ":" and leading 0's for backwards compatibility, but will also accept standard format IP addresses.

4.2.8 Alternate DNS

&AED?	Gets the network interface's Dynamically assigned secondary DNS IP. Return string: &aedX Return value (X): IP in format "xxx:xxx:xxx:xxx" Note: If DHCP is disabled command will return "000:000:000:000" for the IP address. Note: Unit will accept command without (?) for backwards compatibility.
&AES#	Gets/Sets the network interface's static secondary DNS IP. Input Options (#): IP address, ? = Query Return string: &aesX Return value (X): IP in format "xxx:xxx:xxx:xxx" Note: Unit will accept IP addresses separated with ":" and leading 0's for backwards compatibility, but will also accept standard format IP addresses.

Legacy Protocol

Other Commands

SCHOTT
glass made of ideas

4.3 *Sockets*

4.3.1 Legacy Ethernet Socket

4.3.1.1 *Enable*

&ALE#	Gets/Sets if the socket is enabled. Input Options (#): 0 = Disabled, 1 = Enabled, ? = Query Return string: &a1eX Return value (X): 0 = Disabled, 1 = Enabled
------------------	--

4.3.1.2 *Port*

4.3.1.2.1 *Legacy*

&AP#	Gets/Sets the socket port. Input Options (#): 0 - 65535 = Port Number, ? = Query Return string: &a1pX Return value (X): 0 – 65535
-----------------	---

4.3.1.2.2 *CV-LS*

&ALP#	Gets/Sets the socket port. Input Options (#): 0 - 65535 = Port Number, ? = Query Return string: &a1pX Return value (X): 0 – 65535
------------------	---

4.3.1.3 *Connected IP*

&ALK?	Query the IP address of the currently connected user of the socket. Return string: &a1kX Return value (X): IP in format “x.x.x.x”
------------------	--

4.3.1.4 *Kick*

&ALK	Forcefully disconnect current user from the socket. Return string: &a1k
-----------------	---

Legacy Protocol

Other Commands

SCHOTT
glass made of ideas

4.3.2 Binary Ethernet Socket

4.3.2.1 *Enable*

&ABE#	Controls if the socket is enabled. Input Options (#): 0 = Disabled, 1 = Enabled, ? = Query Return string: &abeX Return value (X): 0 = Disabled, 1 = Enabled
------------------	---

4.3.2.2 *Port*

&ABP#	Gets/Sets the socket port. Input Options (#): 0 - 65535 = Port Number, ? = Query Return string: &abpX Return value (X): 0 - 65535
------------------	---

4.3.2.3 *Connected IP*

&ABK?	Query the IP address of the currently connected user of the socket. Return string: &abkX Return value (X): IP in format “x.x.x.x”
------------------	--

4.3.2.4 *Kick*

&ABK	Forcefully disconnect current user from the socket. Return string: &abk
-----------------	---

Legacy Protocol

Other Commands

SCHOTT
glass made of ideas

4.4 *UART*

4.4.1 Baud Rate

&UB#	Gets/Sets the baud rate of the UART port. Input Options (#): ? = Query, 0 = 110, 1 = 300, 2 = 600, 3 = 1200, 4 = 2400, 5 = 4800, 6 = 9600, 7 = 14400, 8 = 19200, 9 = 38400, 10 = 57600, 11 = 115200, 12 = 230400, 13 = 460800, 14 = 921600 Return string: &ubX Return value (X): See Input Options
-----------------	---

4.4.2 Parity

&UP#	Gets/Sets the parity of the UART port. Input Options (#): 0 = None, 1 = Even, 2 = Odd, ? = Query Return string: &upX Return value (X): 0 = None, 1 = Even, 2 = Odd
-----------------	--

4.4.3 Stop Bits

&US#	Gets/Sets the stop bits of the UART port. Input Options (#): 1 = 1 Stop Bit, 2 = 2 Stop Bits, ? = Query Return string: &usX Return value (X): 1 = 1 Stop Bit, 2 = 2 Stop Bits
-----------------	---

4.4.4 Restart

&UR	Command restarts the UART module to apply new settings. Return string: &ur
----------------	--

5 Other Commands

5.1 *Erase Error Logs*

&03	This command will clear the error log list. Return string: &03
----------------	--

5.2 *System Reboot*

&04	This command will cause the unit to perform a full reboot. This is equivalent to power cycling the unit. Return string: &04
----------------	---