Introduction

In space, nuclear power and other scientific applications optical glass may be exposed to high energy radiation like gamma, electron, proton and neutron radiation. With the accumulation of higher doses this radiation changes the transmittance of optical glass especially near the UV-visible edge of the spectrum.

SCHOTT offers a variety of radiation resistant glasses covering main parts of the Abbe diagram. These glasses are suitable for earth orbit based applications with lifetimes of up to 10 years. This paper gives background information on the impact of radiation on the transmittance of optical glass and how the introduction of cerium in the composition improves the radiation resistance of optical glass.

1. Origin of the effect 1
2. Properties of radiation resistant glasses from SCHOTT
3. The effect of radiation on radiation resistant glasses from SCHOTT
4. Notes on the availability7
5. Literature

1. Origin of the effect

lonization caused by photon and particle radiation changes the transmittance of optical glasses. An absorbed radiation dose of 10 Gy (10³ rad) gamma radiation leads to recognizable loss in transmittance over the complete visible spectral range. The loss of transmittance is most pronounced at the UV-edge of the spectrum leading to a color change. Most glasses become unusable for optical applications if the radiation is increased to 100 Gy. The intensity of the color change does not only depend on the type of radiation dose but also on the energy of the ionizing radiation and the radiation dose rate.




Fig. 1-1: Effect of gamma radiation at different doses of absorbed radiation.

Other environmental conditions like temperature and illumination conditions have an impact on the extent of coloration of the glass. The coloration itself is not stable. After the end of the radiation impact the transmittance decreases slightly. This effect is called fading. The following diagram shows the effect of gamma radiation on the internal transmittance of BK7. A dose of 100 Gy reduces the transmittance over the complete visible spectral range significantly. The loss of transmittance can be further increased by increasing the dose of radiation to 10,000 Gy.

The interaction of radiation takes mainly place within the electron shell leading to electron irradiation, ionization, photo and Compton effect.

The loss of electrons leads to defects centers of different nature: ionization, trapped electrons, trapped holes, ruptured Si-O bonds and non bridging oxygen ions. These defect centers lead to a change in the transmittance curve [1].






Version January 2022

2. Properties of radiation resistant glasses from SCHOTT

Optical glasses can be stabilized against transmittance loss caused by ionizing radiation by adding cerium (Ce) to the composition. The added cerium (a polyvalent ion) changes the intrinsic color of the glass. The transmittance edge is shifted to longer wavelengths. In general the cerium content is kept low enough to keep this effect small.

The extent of stabilization differs from glass type to glass type. Every cerium stabilized glass type shows the letter G and a number as an additional suffix in the glass name. The number in the suffix divided by 10 relates to the additional weight percentage of CeO₂ in the glass. BK7G18 for instance was stabilized against radiation by adding 1,8 w% of cerium into the BK7 glass matrix. In general the higher the cerium content the more the glass is stabilized against higher total doses but the more the intrinsic transmittance is reduced. In addition, the impact to the color change by addition of cerium depends on the glass matrix.

The modified Abbe diagram in figure 2-1 contains all currently available stabilized glass types. The diagram shows that not only the transmittance curve but also the optical position of the stabilized glass types varies slightly from the non stabilized catalog glass.





The following table 2-1 gives a summary of properties for the available radiation resistant glasses. Complete datasheets are available on request. Please note that all radiation resistant glasses except LAK9G15 are usually available in standard bubble quality according to the optical glass catalog. The total allowable cross section of bubbles in LAK9G15 is 0.1 mm² per 100 ccm for bubbles larger 0.03 mm in diameter. A large amount of inclusions < 0.03 mm diameter is typical for this type of glass and cannot be avoided by production means.

Radiation Resistant Glasses	Glass type		n _d	ν_{d}	n _F -I	n _c	n _e	Ve	$n_{F'} - n_{C'}$	n _r	n _c	n _F		n _g	n _h
	BK7G18 520636.252		1.51975	63.58	0.008	174 1	.52170	63.36	0.008233	1.51579	1.51724	1.525	587 1.	52981	1.53345
	K5G20 523568.259		1.52344	56.76	0.0092	222 1	.52564	56.47	0.009308	1.51906	1.52065	1.530	040 1.	53494	1.53919
	LF5G15 584408.322		1.58397	40.83	0.0143	301 1	.58736	40.55	0.014484	1.57739	1.57974	1.594	489 1.	60228	
	LF5G19 597399.330		1.59655	39.89	0.0149	954 1	.60010	39.60	0.015153	1.58970	1.59214	1.607	799 1.	61578	1.62330
	F2G12 621366.360		1.62072	36.56	0.0169	979 1	.62474	36.30	0.017212	1.61298	1.61573	1.633	373 1.	64261	1.65121
	LAK9G15 691548.353		1.69064	54.76	0.0126	612 1	.69364	54.53	0.012721	1.68462	1.68680	1.700	013 1.	70630	1.71205
	SF6G05 809253.520		1.80906	25.28	0.0320	015 1	.81661	25.08	0.03257	1.79491	1.79988	1.833	387		
Radiation Resistant Glasses	$\mathbf{P}_{g,F}$	$\Delta \mathbf{P}_{\mathbf{g},\mathbf{F}}$	CR	FR	SR	AR	PR	α (-30/+7	70) T _g	T ₁₀ ^{7.6}	ρ	НК	τ _i (10/400)	τ _i (10/420	FC
	0.5376	0.0007		0	1	2		7.0	585	722	2.52	580	0.764	0.905	41/37
	0.5500	0.0017		0	1	1		9.0	483	679	2.59	510	0.821	0.924	41/37
	0.5759	0.0008	2	0	1	1.3	2.3	9.3	407	578	3.22	446	0.569	0.833	43/37
	0.5803	0.0036	2-3	2	3.4	2.2	3	10.7	474	606	3.30	410	0.276	0.657	45/39
	0.5831	0.0008	1	0	1	1.3	2.3	8.1	435	604	3.60	428	0.325	0.693	45/39
	0.5462	-0.0055	1–2	2	53.0	1.3	4.3	6.3	634	710	3.53	721	0.292	0.634	46/38
	0.6121	0.0108	4	3	51.3	2.3	3.3	7.8	427	529	5.20	360		-	52/46*

Tab. 2-1: Summary of properties of the radiation resistant glasses from SCHOTT [2].



glass made of ideas

3. The effect of radiation on radiation resistant glasses from SCHOTT

The radiation resistant versions of the glasses are often slightly different in color compared to the standard glasses, as shown for one example in figure 3 - 1 where non stabilized N-BK7 and cerium stabilized BK7G18 are compared. BK7G18 has a yellowish color compared to N-BK7. This yellow color is shown by the shift of the UV-edge of the transmittance curve compared to N-BK7. Figure 3 - 2 shows a comparison of the transmittance curve of BK7G18 and BK7. Additionally the impact of 100 Gy gamma radiation (Co60) on BK7 and a much higher gamma radiation of 8*10⁶ Gy on BK7G18 can be compared. BK7 displays a strong transmittance loss over the complete spectral range whereas the reduction of transmittance of BK7G18 at a radiation amount which is 5 orders of magnitude higher is very low in comparison.




Fig. 3 - 2: Transmittance of non stabilized BK7 and stabilized BK7G18 before and after irradiation (10 mm thickness).



Fig. 3-1: Cerium stabilized BK7G18 and non stabilized N-BK7 in direct visual comparison.

As mentioned before the extent of the coloration depends on the kind of radiation and the radiation dose, which can be clearly derived from figure 3-3 where the transmittance loss of BK7G18 for different kind of radiation: proton particle radiation, electrons, gamma and neutron radiation is shown. Neutron radiation (fluence < $0.15*10^{21}$ n/m² in the example) has the highest impact on the transmittance of BK7G18. The effect of protons (total dose $1.4*10^{18}$ MeV/m² with individual energies between 7 to 50 MeV in the example) and electrons on the transmittance is com-parable (fluence: $8.8*10^{21}$ e⁻/m², energy 0.05 MeV, radiation duration 20.6 h in the example) and in the same region as the 10^5 and 10^6 gamma radiation.



glass made of ideas




Fig. 3 - 3: Transmittance loss of BK7G18 as a function of wavelength for different kind of radiations.

Some glasses are stabilized with a high amount of cerium and are therefore especially suitable for use in surroundings with very high radiation. Other glasses are stabilized to a lower amount. This is mostly the case if the cerium- content influences the transmittance to a higher amount. Figure 3-4 shows a comparison of the influence of gamma radiation 10⁶ Gy on the internal transmittance loss over the wavelengthsfor different radiation resistant glasses. SF6G05 shows a significantly higher transmittance loss compared to BK7G18 or K5G20.

In general all radiation resistant glasses are suitable for earth orbit based application with lifetimes of up to 10 years.




Fig. 3-4: Transmittance loss of different radiation stabilized glasses as a function of wavelength for an absorption of 10⁶ Gy.



glass made of ideas

The results are also summarized in the following tables.

		Experimental internal transmittance loss (10 mm thick sample)						
		BK7G18	K5G20	LAK9G15	LF5G15	F2G12	SF6G05	
	400 nm	- 0.07	- 0.04	- 0.26	- 0.51	- 0.18	-	
	450 nm	-0.04	-0.02	-0.13	-0.9	-0.34	_	
Electron radiation	500 nm	-0.02	-0.02	-0.06	-0.83	-0.27	-0.02	
Fluence 8.8*10 ²¹ e ⁻ /m ² ,	550 nm	-0.02	-0.01	-0.03	-0.73	-0.21	-0.01	
energy 0.05 MeV, irradiation time 20.6 h	600 nm	-0.02	-0.01	-0.03	-0.62	-0.15	0	
	650 nm	-0.01	0	-0.01	-0.55	-0.11	0	
	700 nm	-0.02	0	0	-0.48	-0.08	0	
	400 nm	_	-	-0.16	-0.03	-	-	
Proton irradiation	450 nm	-	-	-0.24	-0.01	-	-	
	500 nm	-	-	-0.09	0	-	-0.04	
Total dose 1.4*10 ¹⁸ MeV/m ² , individual energies between	550 nm	-	-	-0.05	0	-	0	
7 to 50 MeV	600 nm	-	-	-0.03	0	-	0	
	650 nm	_	-	0	0	_	0	
	700 nm	_	-	-0.02	0	-	0	
	400 nm	-0.59	-	_	-0.25	-	_	
Neutron irradiation	450 nm	-0.27	-	-	-0.1	-	-	
	500 nm	-0.2	-	-	-0.04	-	-0.41	
Fluence < 0.15*10 ²¹ n/m ²	550 nm	0	_	-	0	_	0	
	600 nm	-0.11	-	-	-0.04	-	-0.12	
	650 nm	0	-	-	0	-	0	
	700 nm	-0.1	_	-	-0.01	_	-0.11	

Tab. 3 - 1: Internal transmittance decrease of some radiation resistance glasses in dependence of electron, proton and neutron radiation at 10 mm thickness. This data dates back to the first radiation resistance glass catalog from SCHOTT (1980s).





<u>SCHOT</u> glass made of ideas

I

		Experimental internal transmittance loss (10 mm thick sample)									
Gamma radiation	(C060)	BK7G18	K5G20	LAK9G15	LF5G15	F2G12	SF6G05				
	400 nm	-0.05	-0.05	0	-0.15	-0.2	-				
	450 nm	-0.01	-0.02	-0.49	-0.03	-0.08	_				
1*10 ⁴ Gy	500 nm	0	-0.01	-0.21	-0.01	-0.02	-0.21				
1,000 krad	550 nm	0	-0.01	-0.11	-0.02	-0.01	-0.08				
1,000 Mud	600 nm	0	-0.01	-0.06	-0.01	0	-0.02				
	650 nm	0	-0.01	-0.05	-0.01	0	-0.01				
	700 nm	0	-0.02	-0.04	-0.01	0	-0.01				
	400 nm	-0.14	-0.16	0	-0.38	-0.26	_				
	450 nm	-0.02	-0.04	-0.7	-0.07	-0.14	_				
1*10 ⁵ Gy	500 nm	-0.01	-0.03	-0.27	-0.03	-0.03	-0.26				
, ,	550 nm	-0.01	-0.02	-0.14	-0.03	-0.02	-0.09				
10,000 krad	600 nm	-0.01	-0.02	-0.08	-0.01	-0.01	-0.02				
	650 nm	0	-0.02	-0.06	-0.02	-0.01	-0.02				
	700 nm	0	-0.02	-0.05	-0.03	-0.01	-0.02				
	400 nm	-0.13	-0.19	0	-0.22	-0.25	_				
	450 nm	-0.03	-0.06	-0.7	-0.05	-0.15	_				
1*10 ⁶ Gy	500 nm	-0.03	-0.03	-0.25	-0.02	-0.05	-0.23				
,	550 nm	-0.03	-0.02	-0.11	-0.03	-0.03	-0.12				
100,000 krad	600 nm	-0.02	-0.01	-0.06	-0.02	-0.02	-0.06				
	650 nm	-0.02	-0.02	-0.04	-0.03	-0.02	-0.04				
	700 nm	-0.02	-0.01	-0.03	-0.05	-0.03	-0.03				

Tab. 3 - 2: Internal transmittance decrease of some radiation resistance glasses in dependence of gamma radiation at different energy dose at 10 mm thickness. This data dates back to the first radiation resistance glass catalog from SCHOTT (1980s).

4. Notes on the availability

The glass type LF5G15 is an inquiry glass which we do not purposely keep on stock. It is therefore recommended to start a request as early as possible within the project.

The following radiation resistant glasses are off the shelf available:

BK7G18, LF5G19, K5G20, LAK9G15, F2G12 and SF6G05.

5. Literature

[1] The properties of optical glass; H. Bach & N. Neuroth (Editors), Springer Verlag 1998

[2] SCHOTT Optical Glass Pocket Catalogue



SCHO

glass made of ideas

SCHOTT North America, Inc. 5530 Shepherdsville Road Louisville, KY 40228, USA Phone +1 (502) 657-4417 info.optics@us.schott.com Dack to maex

Version January 2022 | SCHOTT Advanced Optics reserves the right to make specification changes in this product fiver without notice

schott.com